



INTERNATIONAL MARKETING, INC. TECHNICAL BULLETIN

SUBJECT: Tire Paint Conversion Checklist

DATE: June 28, 2004

To insure that you have great results please verify tip size and follow these guidelines:

Due to the quality of our tire paints we recommend that you use a 413 Reverse a Clean Tip or a 513 Reverse a Clean Tip for Atec and Fuller Brothers Tire Painter.

1. Depressurize your system
2. Flush your system with hot soapy water, repeat until clean
3. To avoid clogging the gun and tips, make sure there is no dried paint on the down tube of the pump
4. Clean all screens, filters and hoses
5. Flush your system again with fresh water until soapy residue is gone
6. Due to shipping, product may settle so you should stir prior to first using
7. Pressurize your system and spray

On average you should get around 30-40 tires per gallon. This may vary depending on your application and system.

Please feel free to contact a service technician at 1-800-233-7086.

Questions regarding the above technical bulletin may be directed to:

INTERNATIONAL MARKETING, INC.
25 Penncraft Avenue, Suite C
Chambersburg, Pennsylvania 17201
Toll Free: 800-233-7086
E-mail: imi@imiproducts.net
Web Site: www.imiproducts.com